

CONTENTS

VERSION INFORMATION
KEY HIGHLIGHTS
KNOWN ISSUES
RELATED TECHNICAL DOCUMENTATION

VERSION INFORMATION

DroboShare Firmware: Version 1.1.0 [43.14143]

KEY HIGHLIGHTS

This is a release for the DroboShare.

- **Fixes for known issues:**
 - Fixed problem where the DroboShare passwords could be lost
 - Added support for Double-byte characters in file names
 - Resolved issue with file deletion on an NTFS volume and Windows Vista
 - Patched two security vulnerability problems
- **Added support for DroboApps:** visit drobo.com and drobospace.com/developers for more information as it becomes available.

KNOWN ISSUES

- **3476: Symptom:** Cannot rename HFS+ formatted volumes connected to a DroboShare
Condition: In Drobo Dashboard's tools tab there is an option to rename volumes. When attempting to do this with an HFS+ formatted volumes, Drobo Dashboard does not allow you to rename the partition.
Workaround: Place your Drobo into Standby and then connect the Drobo directly to your Mac. Open Drobo Dashboard and rename the volume. Place your Drobo in standby and then reconnect it to the DroboShare

Windows Vista Specific

- **4199: Symptom:** Dashboard hangs with Drobo on a DroboShare when no Internet connection
Condition: In Drobo Dashboard, there is an option to automatically check for software updates. When this option is enabled and there is no Internet connection, Drobo Dashboard will freeze when it discovers a Drobo connected to a DroboShare.
Workaround: Choose one of the following solutions options if you need to use a DroboShare without an Internet connection:

Solution 1: Quit Drobo Dashboard and then establish an Internet connection. Restart Drobo Dashboard and once your Drobo is discovered click on the Advanced Controls button. Under the Tools tab, uncheck 'Check for updates automatically.'. You can now disconnect from the Internet.

Solution 2: Quit Drobo Dashboard and connect your Drobo directly to your PC. Restart Drobo Dashboard and once your Drobo is discovered click on the Advanced Controls button. Under the Tools tab, uncheck 'Check for updates automatically.'. Place the Drobo into standby and reattach it the DroboShare.

RELATED TECHNICAL DOCUMENTATION

Drobo and Drobo Dashboard

Drobo user guide reference documentation is available at the Drobo Support Website:

<http://www.drobo.com/support.html>

- *Knowledge Base*
- *User Guide*
- *Drobo Help for PC*
- *Drobo Help for Mac*